



IoT Based -Skincare Assistant

Subjects : Introduction to NN, CNN and GNN (24AIM113)
Analog system design (24AIM114)

Presented By :

M R Bharath - 24022
Shreeram M - 24023
Machavarapu Sriram - 24024
Mahadev M - 24025

Project Mentors :

Dr. Snigdhtanu Acharya
Dr. Amrutha Veluppal

Introduction



Skin health is essential for overall well-being and is influenced by factors like moisture, oil balance, UV exposure, and acne. Our project integrates hardware sensors namely TCS3200, moisture sensor, DHT11, UV sensor with deep learning models like CNN & Neural Networks to analyze skin conditions and provide personalized skincare recommendations, including morning and night routines, product suggestions, lifestyle changes, ensuring an effective and data-driven skincare approach.

Literature Review

Serial No.	Title	Techniques	Key Contributions
1	Personalized Skincare Product Recommendation System Using Content-Based Machine Learning	Content-based machine learning	Uses skin type, ingredient preferences to recommend skincare products; focuses on user-specific data.
2	Skincare Recommender System Using Neural Collaborative Filtering with Implicit Rating	Neural collaborative filtering, implicit feedback	Uses implicit ratings for personalized skincare recommendations; improves prediction accuracy using neural networks.

Serial No.	Title	Techniques	Key Contributions
3	Detection of Skin RGB Color with a Battery-Free NFC Skincare Device	Battery-free NFC, RGB color detection	Proposes a portable, energy-efficient device for skin color analysis, ideal for integration into skincare apps.
4	AC-Skin: Facial Acne Detection-Based on Intelligent Learning and Large Data Collection of IoT for Smart Skincare	Intelligent learning, large dataset collection, IoT	Leverages IoT data and machine learning to detect acne for personalized skincare solutions.
5	New Directions for Skincare Monitoring: An NFC-Based Battery-Free Approach Combined with Deep Learning Techniques	NFC technology, deep learning	Combines NFC and deep learning for sustainable skincare monitoring, providing real-time analysis.

Research Gaps


Limited Personalization – Current systems lack real-time sensor-based skincare recommendations.

AI-IoT Integration – Few studies combine IoT-based skin monitoring with AI-driven skincare analysis.

Holistic Deep Learning Models – Deep learning is underutilized in skincare.


Real-Time Monitoring – Skincare systems rarely provide adaptive, continuous tracking

Problem Statement



Skincare recommendations are often generalized and fail to consider individual skin conditions, environmental factors, and real-time skin data. Existing systems lack integration of AI, IoT-based monitoring, and deep learning for precise skincare analysis. There is a need for a holistic, personalized skincare recommendation system that analyzes oil levels, moisture, UV exposure, and acne severity using sensors and image processing. Our project addresses this by developing an AI-driven system that provides tailored skincare suggestions.

Workflow



Hardware components

ESP32 Microcontroller

Works on WiFi/Bluetooth.

Collects sensor data, processes it, and transmits results.



TCS3200


Detects RGB intensity. Uses photodiodes to analyze reflected light, converting it into a frequency-based output.



Hardware components


Capacitive Moisture Sensor

Gives an analog output for moisture level detection.
Measures capacitance changes due to moisture variation..




DHT11 Sensor

Measures humidity using a capacitive humidity sensor and a thermistor to provide digital readings.




GUVA-S12SD UV Sensor

Used for UV detection, has a UV-sensitive photodiode to measure radiation and analog output.



System design



Feed forward Neural Network for Skincare Recommendations

Neural networks process sensor data (oil, moisture, UV exposure) for personalized **skincare recommendations**.

Feedforward Neural Network (FNN) is good at handling structured data like moisture, oil, and UV levels. FNN efficiently maps input features to skincare recommendations without needing spatial awareness, making it computationally lighter than CNNs.

Pre Processing Steps :

- **One-Hot Encoding** – Converts categorical sensor data (moisture, oil, UV, etc.) into numerical values.
- **Adding Noise** – Introduces slight noise in features and labels to make the model robust.
- **Feature Scaling** – Uses StandardScaler() to normalize the features to a standard range.

Model Architecture

1. **Input Layer** (Fully Connected) – Takes the processed input features and passes them to the hidden layer.
2. **Hidden Layer** (Fully Connected – Dense) (64 neurons) – Learns patterns from the input features using weighted connections.
3. **ReLU Activation** (reluLayer)
4. **Dropout Layer** – It randomly deactivates 20% of the neurons during training and thus prevents overfitting of the model. This improves generalization.
5. **Output Layer** (Fully Connected – Dense) – Converts features into class probabilities for final classification.
6. **Softmax layer** – converts raw outputs into probabilities between 0 to 1. The final prediction is the class with highest probability. This ensures model outputs interpretable probability values.
7. **Epochs** – 50
8. **Batch Size** – 32
9. **Loss Function** – Cross-Entropy Loss
10. **Accuracy** – 0.90

Model Architecture

Why ReLU activation function in hidden layers ?

If the input is positive, it will keep it as it is, if the input is negative, it will set it to zero. ReLU also keeps gradients large enough for deep networks and avoids vanishing gradient.

Why Softmax in output layer ?

- Converts raw outputs (logits) into probabilities for multi-class classification.
- Ensures that output probabilities sum to 1, making interpretation easier.

Why Cross-Entropy Loss?

Cross-entropy loss is used for classification problems to measure how well the predicted probabilities match the actual labels.

- Helps the model learn faster by focusing on incorrect predictions.
- Works well when outputs are probabilities (like softmax).

CNN for Acne Detection


Deep learning enables accurate skin analysis by extracting features from images and sensor data. **Convolutional Neural Networks (CNNs)** are used for **acne detection** and classification.

CNN is chosen for image-based acne level detection due to its strong feature extraction capabilities.

We are using CNN for acne detection because it excels at **image analysis**, identifying features like pimples while preserving spatial relationships. CNNs are ideal for acne classification due to their strong feature extraction.

Learning curve

A learning curve is a graph that shows how a machine learning model improves over time during training.



Code snippet

The screenshot shows the Arduino IDE interface with a dark theme. The title bar says "sketch_feb6a | Arduino IDE 2.3.4". The menu bar includes File, Edit, Sketch, Tools, and Help. The toolbar has icons for file operations and a connection status. The central editor window displays the code for "sketch_feb6a.ino". The code includes functions for reading digital pins and analog sensors, and prints sensor readings to the serial monitor. The serial monitor window at the bottom shows the received data.

```
sketch_feb6a.ino
35
36     digitalWrite(S2, HIGH);
37     digitalWrite(S3, HIGH);
38     delay(100);
39     blue = pulseIn(OUT, HIGH);
40
41     digitalWrite(S2, LOW);
42     digitalWrite(S3, HIGH);
43     delay(100);
44     green = pulseIn(OUT, HIGH);
45 }
46
47 // Function to Read All Sensors
48 void readSensors() {
49     int moisture = analogRead(MOISTURE_SENSOR);
50     int uv = analogRead(UV_SENSOR);
51     float temperature = dht.readTemperature();
52     float humidity = dht.readHumidity();
53     int red, green, blue;
54     readTCS3200(red, green, blue);
55
56     Serial.println("--- Sensor Readings ---");
}
Output Serial Monitor X
Message (Enter to send message to 'ESP32 Dev Module' on 'COM6')
New Line 115200 baud
Red: 0
Green: 0
Blue: 0
-----
--- Sensor Readings ---
Moisture: 3721
UV: 3423
Temperature: nan °C
Humidity: nan %
Red: 0
Green: 0
Blue: 0
-----
```

Expected output

--- Sensor Readings ---

Moisture Level: Medium
Oil Level: High
UV Exposure: High
Temperature: 30°C
Humidity: 55%

--- Skin Type & Analysis ---

Skin Type: Oily Skin

--- Morning Skincare Routine ---

1. Cleanse: Use a gentle foaming cleanser with salicylic acid.
2. Tone: Apply an alcohol-free toner to balance oil production.
3. Moisturize: Use a lightweight, oil-free moisturizer.
4. Sun Protection: Apply a broad-spectrum sunscreen (SPF 50).


--- Night Skincare Routine ---

1. Cleanse: Use a mild gel-based cleanser to remove excess oil.
2. Exfoliate: Use a BHA-based exfoliant (2-3 times per week).
3. Treat: Apply a niacinamide serum to control oil and acne.
4. Moisturize: Use a water-based, non-comedogenic moisturizer.

--- Recommendations ---

- Choose non-comedogenic, oil-free skincare products.
- Use blotting paper or a clay mask to absorb excess oil.
- Drink plenty of water and maintain a balanced diet.
- Avoid over-washing, as it may trigger more oil production.
- Protect your skin from UV rays by reapplying sunscreen every 2-3 hours.
- Reduce dairy and high-glycemic foods to minimize breakouts.

Timeline



References

- [1] M. Vinutha, R. B. Dayananda and A. Kamath, "Personalized Skincare Product Recommendation System Using Content-Based Machine Learning," 2024 4th International Conference on Intelligent Technologies (CONIT), Bangalore, India, 2024, pp. 1-6, doi: 10.1109/CONIT61985.2024.10626458. keywords: {Industries;Visualization;Accuracy;Filtering;Machine learning;User interfaces;Skin;Machine Learning;Content-Based Filtering;Skincare;Recommendation System;Personalization;Cosmetics;Beauty Impact},
- [2] C. Qalbyassalam, R. F. Rachmadi and A. Kurniawan, "Skincare Recommender System Using Neural Collaborative Filtering with Implicit Rating," 2022 International Conference on Computer Engineering, Network, and Intelligent Multimedia (CENIM), Surabaya, Indonesia, 2022, pp. 272-277, doi: 10.1109/CENIM56801.2022.10037471. keywords: {Sentiment analysis;Collaborative filtering;Multimedia systems;Collaboration;Product design;Quality assessment;Electronic commerce;Neural Collaborative Filtering;Skincare Recommender System;sentiment analysis},
- [3] S. M. Ali, T. -B. Nguyen and W. -Y. Chung, "New Directions for Skincare Monitoring: An NFC-Based Battery-Free Approach Combined With Deep Learning Techniques," in IEEE Access, vol. 10, pp. 27368-27380, 2022, doi: 10.1109/ACCESS.2022.3155811. keywords: {Skin;Sensors;Moisture;Conductors;Temperature sensors;Moisture measurement;Intelligent sensors;Artificial neural network model;near field communication;skin moisture;skincare;UVI},

References

[4] U. Khalid, C. Li, A. Ayub Khan and F. Mehmood, "AC-Skin: Facial Acne Detection-Based on Intelligent Learning and Large Data Collection of Internet of Things (IoT) for Smart Skincare," in IEEE Sensors Journal, vol. 24, no. 19, pp. 30769-30777, 1 Oct.1, 2024, doi: 10.1109/JSEN.2024.3414148.

keywords: {Skin;Convolutional neural networks;Internet of Things;Diseases;Artificial intelligence;Medical diagnostic imaging;Medical diagnosis;Acne detection;artificial intelligence (AI);convolutional neural network (CNN);Internet of Things (IoT);severity detection;smart skincare},

[5] S. M. Kumar, R. Thenmozhi, T. S. Balaji Damodhar, P. Epsiba, N. Malathi and B. Meenakshi, "Data-Driven with IoT Sensing and Deep Learning Model for Dynamic Skin Cancer Diagnosis," 2024 2nd International Conference on Self Sustainable Artificial Intelligence Systems (ICSSAS), Erode, India, 2024, pp. 1034-1039, doi: 10.1109/ICSSAS64001.2024.10760605. keywords: {Deep learning;Training;Measurement;Technological innovation;Recurrent neural networks;Accuracy;Skin;Real-time systems;Internet of Things;Skin cancer;Personalized Skincare;Skin Parameters;Environmental Factors;Personalized Recommendations;Early Detection;Adaptive Skincare Routines},

Datasets

Acne dataset : <https://www.kaggle.com/datasets/nayanchaure/acne-dataset>

Skincare recommendation dataset : <https://www.kaggle.com/code/melissamonfared/skincare-products-edasentiment-analysis>



The background features a series of concentric, wavy lines in a light purple color. These lines are most dense on the left side and taper off towards the right, creating a sense of depth and motion. The overall effect is reminiscent of a stylized sunburst or a microscopic view of a cellular structure.

Thankyou